

Date of sending : 2023.11.23 Filename : 724yXRUDA(V2.13_B11B).bin
Rom-ID : 724yXRUDA(V2.13_B11B)
Type : V7
System(Control) : 724
Device(Protocol): yX (Pulse+ICT004+M.D.B_US)
MDB Version : 4.2 (Software Version: 2.13)
Online Upgrade : None
ICT Verification: None
Judgement(Notes): RUDA
Checksum : B11B
Currency : RUB
Accepted notes : 50(2001~2004) 、
 100(Old 2001~2004,New 2022) 、
 200(2017) 、
 500(Old 2001~2004,New 2010) 、
 1000(Old 2001~2004,New 2010) 、
 2000(2017) (6 bills)
Accepted ways : 4

Dip switch settings:

- 1 ON : Reject Ruble 50
 * OFF: Accept Ruble 50

2 ON : Reject Ruble 100
 * OFF: Accept Ruble 100

3 ON : Reject Ruble 200
 * OFF: Accept Ruble 200

4 ON : Reject Ruble 500
 * OFF: Accept Ruble 500

5 ON : Reject Ruble 1000 & 2000
 * OFF: Accept Ruble 1000 & 2000

6 ON : Reserved
 * OFF: Reserved

 ON : Harness Disable
7 * OFF: Harness Enable

 ON : Inhibit Active High
8 * OFF: Inhibit Active Low

----- ----- -----								
ICT004 Interface		Pulse Mode				MDB Mode		
----- ----- -----								
SW2		SW2				SW2		
----- ----- -----								
1	ON : Reserved	1	*OFF	ON	OFF	ON	1	ON : Reserved
	OFF: Reserved	2	*OFF	OFF	ON	ON		OFF: Reserved

724yXRUDA(V2.13_B11B).txt

2	ON : Reserved OFF: Reserved	1 Pulse 2 Pulses 5 Pulses 50 Pulses / Ruble 50	2	ON : Reserved OFF: Reserved
3	ON : Reserved OFF: Reserved	3 *OFF ON OFF ON 4 *OFF OFF ON ON	3	ON : Reserved OFF: Reserved
4	ON : Reserved OFF: Reserved	50ms Lo 60ms Lo 30ms Lo 150ms Lo 50ms Hi 300ms Hi 50ms Hi 150ms Hi	4	ON : Reserved OFF: Reserved
SW3 (internal)		SW3 (internal)	SW3 (internal)	
1	ON : Reserved * OFF: Reserved	1 * ON : Credit-Pulse Normal HIGH OFF: Credit-Pulse Normal LOW	1 * ON: Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 OFF : Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	
2	OFF	2 ON	2	OFF
3	ON ->ICT004 Interface(**)	3 OFF ->Pulse Interface(**)	3	OFF ->MDB Interface(**)
4	ON : Reserved * OFF : Reserved	4 ON : Reserved * OFF : Reserved	4	ON : Reserved * OFF : Reserved

NOTE @

- * Default setting
- ** Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
- *** Remove the front cover and the dip-switch in on the CPU board.
(Please refer to "SW1" setting.)

CURRENCY ASSIGN DATA (RUB)			
	ICT004	Pulse	MDB
BV1			
BV2	Ruble 50	Ruble 50	Ruble 50
BV3	Ruble 100	Ruble 100	Ruble 100
BV4	Ruble 500	Ruble 500	Ruble 500
BV5	Ruble 1000	Ruble 1000	Ruble 1000
BV6	Ruble 200	Ruble 200	Ruble 200
BV7	Ruble 2000	Ruble 2000	Ruble 2000

Bezel LED & Back LED lights display list:

1.Bill Acceptor in the idle state Bezel LED display:

Setting	Display

	Colorful light.
	The blue light flashes.
*	The green light flashes.
	No light.

2.Bezel LED Errors:

Green	Status
1	White Card Calibration.

3.Back LED Errors:

LED Flashes	Status
Green	
1	Bill Jammed.
2	Disable.
3	Recognition sensor error.
3+2	Hook sensor error.
3+5	Magnetic Head error.
(Optional)	
4	Anti-string sensor error or A stringing attempt has detected.
5	Bill box has been removed.
6	Stacker error or stacker full.
7	Motor error.